

AQUAPAC Fit Guide - Phones

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Alcatel Amoisonic Motorola NEC Nokia Panasonic Philips Sagem
 Samsung Sendo Sharp Seimens Sony Sony Ericsson Treo Trium

Make/Model	Phone/GPS Case
Alcatel	
300/301/302/303	Mini
500/501/525/511	Mini
700/701	Large
Max/Gum/View (db)	Mini
Easy/Club	Medium
Amoisonic	
A6/A8	Flip Phone
Apple	
iPhone	Mini Phone / PRO Sports Mini / PDA Classic / PDA Wallet
Motorola	
191 Talkabout	Mini
192 Talkabout	Mini
205 Talkabout	Mini
250/270c Timeport	Small
A760/	Flip Phone
A835/A920/A925	Medium
C336/333	Mini
450	Micro
CD930	Medium
G60/ GD67	Mini
GD87	Flip Phone
i1000plus	Large
i2000plus	Medium
i700plus	Medium
L7082/7089/7382/7389 Timeport	Small
M3682	Large (with flip open)
M3788	Small
P7382/7389 Timeport	Small
P8090/8097/8160/8167/8767 Timeport	Large
RAZR V3	Medium (Is not suitable for Flip-Phone)
SC3160	Large (with Flip Open)
SLVR L7	Mini
ST7760/7762 StarTAC	Flip Phone
ST7790/7797 StarTAC	Flip Phone
ST7860/7867/7868 StarTAC	Flip Phone
StarTAC 3000/6500	Flip Phone

AQUAPAC Fit Guide - Phones

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Alcatel Amoisonic Motorola NEC Nokia Panasonic Philips Sagem
 Samsung Sendo Sharp Seimens Sony Sony Ericsson Treo Trium

Make/Model	Phone/GPS Case
T180/250/192	Small
T2260/2267 Talkabout	Small
T2282	Medium
T2288/2290/2297 Talkabout	Small
T2988 Talkabout	Small
T8090/8097 Talkabout	No fit
T8160/8167/T720 Talkabout	Flip Phone
V120c	Small
V2282/2288/2290/2297	Small
V2260/2267/2397	Medium
V265/V3	Flip Phone
V270c	Medium
V3620/3682/3690	Flip Phone
V50/60c/66/V600/V300	Medium (with Flip Open)
V557	Flip Phone
V8088/V8160	Medium (with Flip Open)
V8162	Large (with Flip Open)
X70	Large
NEC	
DB2000	Small
DB4000	Large (with flip open)
DB500	Small
N22i	Flip Phone
Nokia	
918	Medium
5510	Medium
6800	Medium
2100/5100/3210/3410/3310/3390/5210	Mini
2160/2170/2180/2190	Medium
282/7650	Medium (with Flip Open)
3510/7210/1100	Mini
3587i	Mini
505/540/6220/6510/3310/3200/6300/6600	Mini or Micro
5110/5120/5125/5130/5160/6650	Medium
5165/5170/5180/5185/5190	Small
6100/6610/7250/8210/8260/8290/8310	Mini or Pager Case
6110/6120/6130/6150/6160/6185/6190	Small
6161/6162	Large (with Flip Open)

AQUAPAC Fit Guide - Phones

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Alcatel Amoisonic Motorola NEC Nokia Panasonic Philips Sagem
 Samsung Sendo Sharp Seimens Sony Sony Ericsson Treo Trium

Make/Model	Phone/GPS Case
6210/6310/6310i	Small (Older versions of the 6210 suffer a feedback problem inside an Aquapac)
6250	Medium
6680/	Small
6300/6330	Mini
6230/6233	Mini
636/638	Small
640/650	Medium
6950/2270/3520/3586/	Mini or Pager Case
7110/7160/7190/7650	Small (Large, if Slider is needed)
8800/	Small (with slide open)
8810/8850/8860/8890/8910i	Small (or Medium, if Slider is needed)
9000/9110/9210	Large
NGage	Medium (closed)
rinGo	Mini
Panasonic	
Duramax	Medium
GD35/52/55/67/90/92/93/95	Mini or Micro
GD87	Flip Phone
Promax	Small
X70	Large
Philips	
630/330	Medium (with flip open)
Azalis	Small
Fisio	Mini
Genie	Mini
Ozeo	Small
Savvy	Small
Xenium	Mini
Sagem	
3000/3040	Medium
3020/3042	Mini
912/916/920/932/936/940/950	Mini
929/939/959/979	Mini (or Large if flip open)
MY-X 5	Mini
Samsung	

AQUAPAC Fit Guide - Phones

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Alcatel Amoisonic Motorola NEC Nokia Panasonic Philips Sagem
 Samsung Sendo Sharp Seimens Sony Sony Ericsson Treo Trium

Make/Model	Phone/GPS Case
600/6100	Large (with Flip Open)
850/8500	Large
A-890	Flip-Phone
A100/110/200/288/300/800/500	Medium (with Flip Open)
D700	Large (with flip open)
E400/E700	Large (with Flip Open)
i500/X410/X400	Large
M100	Large (with Flip Open)
N100/Q100	Large (with Flip Open)
P400/P410/V200	Large (with flip open)
S300/S100/Q300/Q200	Medium (with flip open)
T700/T500/T400/T200/T100	Small or Medium (with flip open)
Uproar	Medium
V100/V200	Large
Sendo	
D800	Mini (or Medium with Flip Open)
J530	Mini
M550	Medium (with flip open)
S230	Mini
Sharp	
GX 10/GX 20	Large (with flip open)
Siemens	
A35/A55/A50	Mini
A36/A40	Mini
C25	Mini or Small
C30	Mini
C35/C55	Mini
CL50	Small
M30	Small
M35/M55/M50/MC60	Mini
S25	Small
S35/S55/ST55	Mini
S40	Mini
SL45/SL55	Mini or Micro
SX1	Mini or Small
U10	Medium

AQUAPAC Fit Guide - Phones

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Alcatel Amoisonic Motorola NEC Nokia Panasonic Philips Sagem
 Samsung Sendo Sharp Seimens Sony Sony Ericsson Treo Trium

Make/Model	Phone/GPS Case
Sony	
CMD-C1	Small
CMD-C1	Small
CMD-CD5	Small
CMD-CD5	Small
CMD-J5	Small or Mini
CMD-J5	Small
CMD-X2000	Small
CMD-X2000	Small
CMD-Z1 plus	Medium
CMD-Z5	Medium (or Large with Flip Open)
P800	Medium (or Large with Flip Open)
Sony Ericsson	
A1018/A1228/A2618/A2628	Medium
K700i /K750i	Mini or Pager
R310/R380/R520	Medium
R320/R280	Small
R600	Mini
T10/T18/T20	Large (with flip open)
T28/Z600	Medium (with flip open)
T65/T100/T200/T230/T300/T310/T630	Mini
T68/T610(i)	Micro
P900	Medium
W800	Mini
Treo	
Palm 600	PDA Classic case
Palm 650	Medium Phone or PDA Classic
Trium	
Aria	Small (or Large with Flip Open)
Astral	Small
Cosmo	Mini
Galaxy	Small (or Large with Flip Open)
Geo	Small (or Large with Flip Open)
Mars	Medium
Neptune	Medium